




Battery Tester

User Manual

RND 305-00028

Universal Battery Charger



1. LCD Display

LCD-Anzeige

2. 9V Battery Slot

9V Batterie Slot

3. CR2 Battery Slot

CR2 Batterie Slot

4. N Size Battery Slot

N-Steckplatz für Batterie

5. CR123A Battery Slot

CR123A Batteriefach

6. AAA Battery Slot

AAA Batterie Slot

7. AA / C Battery Slot

AA / C Batterie Slot

8. D Size Battery Slot

D-Größen-Batterie Slot

9. 2CR5 & CR-P2 Battery Slot

2CR5 & CR-P2 Batterie Slot

10. 3.0V Li-ion & 1.5V Button Cell Slot

3.0V Li-ion & 1.5V Knopfzelle Slot

11. CR-V3 Battery Slot

CR-V3 Batterie Slot


12. LR03 battery (power supply)


LR03 Batterie (Netzteil)

Using Your Device

Verwenden Sie Ihr Gerät

- Remove the Clear Plastic Strip
Entfernen Sie den durchsichtigen Plastikstreifen
- Insert battery you wish to test
Legen Sie den getesteten Akku ein





RND
power

www.rnd-electronics.com