






Using Steps

Switch S1, S2, and S4 to different positions, and the potentiometer can adjust different time ranges.

S1	S2	Null S4	Insert S4	Illustration
0	1	0.13S-1.3S	1.5S-14.5S	 S1 S2
1	0	0.5S-5.2S	6S-58S	 S1 S2
0	0	4.4S-42S	48S-463S	 S1 S2
1	1	38S-340S	389S-3700S	 S1 S2



When S5 is plugged in, VCC is connected to the common terminal of the relay. If the relay controls AC, it cannot be plugged in, otherwise high voltage will flow back into the module and burn it out.



Product Photos

